

CAPTIS ON TELSTRADEV QUICK START GUIDE

CAPTIS PULSE LITE



STEP 1. WHAT YOU NEED – PREREQUISITES

- **CAPTIS compatible sensor**
This is not available from Telstra. This will need to be purchased separately. [Click here to view supported sensor specifications](#)
- **CAPTIS Device: CAPTIS Pulse Lite**
- **Connectivity to the Telstra IoT Network**
CAPTIS devices come with a built-in connectivity SIM with a data allowance of 10MB per month. A recurring fee of \$5.50 will be charged at the start of each month for this data allowance. [Click here for more details on the data plan.](#)
- **Telstra IoT Platform Tenancy**
This can be purchased separately from <https://buyiot.telstra.com>.
[Click here for more details on purchasing a Telstra IoT Platform Tenancy.](#)

STEP 2. CERTIFICATION REQUIRMENTS FOR INSTALLATION

- In order to have a valid warranty on your CAPTIS device, you need to become a certified authorised installer.
- Please visit <https://www.miot.com.au/support/training/> to submit your request to become a certified authorised installer.
- Following the submission of this form, you will receive a call from mIoT (our device partner) to process your payment details and confirm your enrolment for the online certification training program
- Certification cost is \$150 (including GST).

STEP 3. INSTALLATION

- The CAPTIS Pulse Lite Installation Guide provides information on how to activate the device, connect compatible sensors and mount the device on a chosen location.
[Click here to view the CAPTIS Pulse Lite Installation Guide.](#)
- Once the device installation has been completed, the device has be to be set up and configured on the Telstra IoT Platform. [Click here to view configuration instructions.](#)